



The valve is commonly used to direct oil from the pressure side of a bidirectional hydraulic motor to a pressure-released hydraulic brake. When using this valve as shown above, an A&B-to-tank spool (motor spool) must be used so that the motor brake can drain when the valve is centered.